



ALCATEL OMNIPCX –ANALOGUE USER GUIDE

Analogue terminals have most of the functionality of a digital terminal. However accessing these functions is completed mainly by using the 'R' (recall) key and digits:

CALL PICKUP FROM AN EXTENSION IN YOUR GROUP:

14

CALL PICKUP WHEN ANOTHER EXTENSION IS RINGING:

13 + Extension Number

CANCEL ALL DIVERTS:

60

CANCEL CALL BACK:

19

DIVERT YOUR CALLS ON BUSY:

62 + Extension Number calls are to go to

DIVERT YOUR CALLS TO ANOTHER EXTENSION:

61+ Extension Number calls are to go to

Or

Externally 61+ 9 + Telephone Number

DO NOT DISTURB:

63

MAKE A 2ND CALL WHILST 1ST CALL IS IN PROGRESS:

R + Extension Number

Or

Externally R + 9 and Phone Number

RELEASE 2ND CALL:

R 3

REQUEST AN AUTOMATIC CALL BACK FROM A BUSY EXTENSION:

R 19

SPEED DIAL:

7000 range (7001, 7002 etc)

SWITCHING BETWEEN CALLS WHILE IN CONVERSATION:

R 2

THREE WAY CONFERENCE CALL:

R 50

TRANSFERRING A CALL:

R + Extension Number + replace handset

VOICE MAIL RETRIEVAL:

800

VOICE MAIL SET UP:

50